













ASSEMBLY INSTRUCTIONS

MODEL: 2422




Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON:

Ax1 	Hx3  M8x25
Bx1 	Jx3 
Cx1+1 	Kx3 
Dx1 	Lx4  M6x35
Ex1 	Mx2  M6x25
Fx5 	
Gx1  Mx6	

INSTRUCTIONS:



⚠ ATTENTION ⚠

Do not tighten any screws or bolts until the unit is completely assembled.

Ensure all bolts and screws are tightened before using the table, check bolts and screws every 6 months.

If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts.

Failure to follow these warnings may result in injury.